

Storm Sentinel® Curb Basin Insert

SKU: 4320-CURB



Installation:

- 1. Remove catch basin grate.
- 2. Remove dirt and debris from grate and basin edges.
- 3. Position the filter coil against the curb inlet. The edges of the coil should extend beyond the opening on both sides.
- 4. Insert catch basin filter into drain.
- 5. Reinstall grate. To ensure maximum effectiveness, fabric of filter should be fully captured between grate and edge of basin.
- 6. Check that there are no gaps between the filter coil and ground.
- 7. If desired, use a utility knife to cut excess fabric around the grate.

Removal:

- 1. Lift one end of catch basin grate while keeping the other side on ground. This keeps the storm drain filter from falling into hole.
- Secure the storm drain filter by holding yellow handles. The catch basin grate can now be fully removed from the storm drain filter.
- 3. Lift and remove storm drain filter using yellow handles.
- 4. Dispose of contaminated Storm Sentinels® according to all local, state and federal regulations. Contact your local disposal authority for more information.
- 5. Replace and install new filter.



