



PRODUCT INSTRUCTIONS

SKU: BC-21

PLUG GASOLINE AND DIESEL LEAKS

Note: No surface preparation is needed.

1. When ready to use, add 4 oz. (cup included) of water into the bag.
2. Knead into a stiff paste (approximately 30 sec).
3. Apply directly into and around the leak.