


Wire L-Bracket Berm Instructions

For Black Diamond's L-Bracket Berms

1. If a Ground Pad has been purchased (sold separately), roll out the Ground Pad before unfolding the berm.
2. Unfold the berm to lay flat (position on top of Ground Pad if purchased).
3. Squeeze the opened wires together to insert into each pocket on the outside of the berm.



4. Continue until all brackets are placed in the slots around the perimeter.
5. If a TracMat (sold separately) was purchased, take the brackets out of a short end of the berm. Unroll the TracMat inside the berm, this mat should be positioned to align with vehicle tires.
6. Brackets may require adjusting for the brackets to sit 90 degrees on the ground and the fabric adjusted to sit on the bracket.



Note: Wire brackets must be removed for vehicle entry and exit. Once vehicle has entered the berm, the wire brackets should be put back into slots for full containment.