

Assembly Instructions

ENPAC Large and Extra Large Tote Bin with Wheels Part Number: 1510, 1511, 1530, & 1531

1. Locate the wheel kit. The wheel kit is packaged inside of the tote. If the wheels are to be installed onto a loaded unit, make sure that the lid is secure to ensure that the contents do not spill during installation.
2. Review wheel kit to ensure all components are included. The wheel kit includes (16) 5/16" -18 x 1.25" long bolts, (16) 5/16" lock washes, (2) fixed casters, and (2) swivel casters. Use (1) bolt and (1) lock washer per hole to attach the caster to the threaded inserts in the bottom of the tote.



3. Assemble similar casters (swivel or fixed) onto the same side that the unit will be pushed from. ENPAC recommends the casters are positioned per the image below, with fixed casters on one side of the forklift channels and the swivel casters on the opposite side of the forklift channels.



4. The tote is now ready to be utilized.

Visit www.ENPAC.com for additional images of the finished product.
Still need help? Contact ENPAC Customer Service at (800) 936-7229 for assistance.