

Stinger Rail Track Berm Instructions

SKU: 48-RSB-FS



Fig. 1

1. Unfold and unroll the berm.
2. Determine the area where the berm will be in position. The berm should be positioned under the dispensing valves of the railcar.
3. Once the berm has been confirmed to be in the correct position in Fig. 1, then insert foam logs into each perimeter sleeve. Two short foam logs are for the outside of the rail and three long foam logs are for the walls in the center of the track (Fig. 2).
4. Continue until all foam logs have been inserted.
5. 2" drains available with male CAM-LOC fitting for hoses (Fig. 3).

Fig. 2



Fig. 3

