

Salvage Drum Dolly Product Instructions SKU: 8050

ATTENTION: TO ENSURE SAFE AND EASY USE OF YOUR ENPAC DRUM DOLLY, READ THESE INSTRUCTIONS BEFORE USING.

General Safety Information

This drum dolly is itended for the transport of ENPAC® Salvage Drums: 1230-YE, 1065-YE, 1295-YE, 1095-YE, and 1040-YE. This drum dolly can also be used with industry standard 30, 55, and 85-gallon steel or poly drums.

Adhere to the following instructions to ensure safe and proper use.


- 1. Maximum load capacity 900 lbs. (408.2 kg.)
- 2. Do NOT exceed rated capacity. Injury to persons or property may result from overloading and misuse.
- 3. Do NOT use on inclines.
- 4. Ensure all bolts are completely tightened before use.
- 5. Periodically check for loose or worn hardware, replace any at once.
- 6. Do NOT operate a damaged unit until it is completely repaired.
- 7. Warranty is voided if custom alterations to the drum dolly are not made at the factory.

Wheel Assembly Instructions

- 1. Place the dolly carefully on a level surface with the rim side down.
- 2. Place the Caster on top of the Cross Brace (4) hole pattern.
- 3. Insert one Carriage Bolt through the far side and attach the Washer and Nut (as shown below).
- 4. Repeat step 3 until all Casters are secured to the dolly.
- 5. Ensure all bolts are tightened before use.

Check all contents before installation. Contents:

(1) Drum Dolly (4) Caster Wheels (16) Carriage Bolts (1/4"-20 x 3/4") (16) Washers (1/4" SAE) (16) Nuts (1/4"-20)



REV: 06 BY: K.H. DATE: 12/10/2024