

## **Stinger Spillpal One-Piece Berm Instructions**

1. If a Ground Pad has been purchased (sold separately), roll out the Ground Pad before unfolding the berm.
2. Unfold berm to lay flat (position on top of Ground Pad if purchased).
3. If a TracMat (sold separately) was purchased, unroll the TracMat inside the berm, this mat should be positioned to align with vehicle tires.



**Note: Vehicles can enter and exit from ALL sides of this berm.**