

Poly-Dolly® Product Instructions

SKU: 5300-YE, 5300-YE-A

1. Stand the dolly upright against the drum.
2. Holding on to the dolly, slip both lengths of the barrel strap over the drum (Image 1).
3. Tighten the barrel strap snugly.
4. Use a drum tipper, or other suitable means, to tip the top of the drum away from the dolly. The dolly should then slip under the drum.
5. Ensure that the drum is fully on the dolly platform before proceeding. If necessary, repeat Step 4.
6. Tighten the barrel strap snugly again.
7. Holding the handles, stand on the kickplate with one foot. From this position, shift your weight back to your free foot and pull down towards your body in a continuous motion (Image 2).



Watch the Poly-Dolly® Product Instructions on YouTube:

<https://www.youtube.com/watch?v=Q0gEPWErAdM>