

Drive-Over Modular Diverter Berm Kit Instructions

SKU: 48-212-BK-DBKIT

Contents:

- (1) 12' Straight Section
- (6) 4' Aluminum Batten Strips
- (1) Sili-Thane Sealant

You may need (not included):

- Caulk
- Floor anchors (see note below)
- Utility Knife

Note: You may need caulk to repair any cracks and/or separations in the containment area. These should be filled to seal the area, and dried, prior to installation of the Diverter Berm.

Note: Batten strips include pre-drilled holes, specifically designed for 1/4" diameter anchors. You will need to refer to your anchor instructions to choose the correct drill bit size and depth required for your anchors. The type of anchors will depend on what floor you will be anchoring to.

1. Clean the surface where the Diverter Berm will be installed. Remove any debris or contaminants that may interfere with the sealant.
2. Lay out the Diverter Berm piece to determine if the piece needs to be cut to fit the size of your containment area. Make sure there is at least an extra inch of material at each connection point for applying adhesive (step 6). Mark the piece for cutting.
3. Cut pieces to size using a utility knife with a straight edge.
4. Lay your pieces out in their desired locations. Place batten strips on both 1" edges and mark the hole locations.
5. Drill holes for anchoring (refer to anchoring instructions) and clear debris from the area from drilling.
6. Apply Sili-Thane on the bottom of the diverter berm about 0.5" from the outer edge and on both sides. This should be applied in a continuous line to ensure a complete seal. (Figure 1)



Figure 1

7. Place the Diverter Berm sections to the floor, aligning the holes in the berm to the anchor/drill holes.
8. Place the batten strips over the diverter berm holes.
9. Insert the anchors into the drill holes and follow any remaining anchor instructions.
10. Refer to Sili-Thane instructions for drying time. Additional Sili-Thane can be used for uneven surfaces to ensure a proper seal.

Note: If joining to other Diverter Berm sections, use vinyl cement to seal the joints. Vinyl cement is included in the Modular Diverter Berm Kit (48-250-DBKIT) and sold separately (ENP VINCEM) by ENPAC. Refer to the Modular Diverter Berm Kit instructions for vinyl cement application.