



## PLUG N DIKE, DRY GRANULAR PRODUCT INSTRUCTIONS

NO SURFACE PREPARATION IS NECESSARY. PLUG THE LEAK EVEN IF SURFACE IS DIRTY AND HAS FLUID FLOWING OVER IT

1. Put on latex gloves.
2. Take equal parts granular Plug N Dike and water and mix together. It is easiest to complete the mixing in a one quart or larger Ziploc bag.
3. Knead together for 30 seconds to form a sticky paste. Use enough water so it is thoroughly wetted and molds into a ball.
4. Take the paste and apply it directly into and around the edges of the leak. Work it and press down to get good adhesion.
5. Apply enough Plug N Dike to get a good thick layer over the leak. Additional Plug N Dike can be added over the top. Not for use on urethane or Teflon surfaces.
6. Will plug up to 3 feet of head.

Non-toxic and non-flammable.

Store above freezing unless using the Plug N Dike Low-Temp.

**Not** recommended for use plugging containers of antifreeze, acids, bases, or oxidizers.

**Non-warranty:** The above suggestions and data are based on work done in the lab and field results. Because the storage, handling, and application are beyond our control, the manufacturer and seller accept no liability for the results obtained.

All included information is proprietary for ENPAC LLC